

1 The first step to calibrate for any OHP herbicide is to determine the rate required (lbs./A), located in the left hand column below. (To determine the setting for Marengo G, for example, at 200 lbs./A, refer to the Marengo G column. The 200 lbs./A setting is line mark 4.)

2 Next, place the calibration pan on the ground, apply the product using a comfortable pace, passing over the pan. When finished, tilt calibration pan up, tap the product evenly into the corner collection well.

3 Determine lbs./A by viewing the level of the product within the window line marks. Adjust your pace (slower to increase rate, faster to decrease rate) and equipment settings to deliver the correct rate.

* Verge granule

Biathlon is a registered trademark of OHP, Inc.

Marengo is a registered trademark of Bayer. Casoron is a registered trademark of Chemtura Corporation.

Rate	Biathlon [®]	Marengo [®] G*	Casoron [®]
100 lbs./A	2	2	3
150 lbs./A	3	3	4
200 lbs./A	4	4	5
400 lbs./A	N/A	8	N/A



ohp.com

(800) 356-4647

